



Electrical equipment

- | | |
|--|---|
| <ul style="list-style-type: none"> 1 Engine compartment light switch 2 Engine compartment light bulb 5 W 3 DistributorBosch JF 4 4 CoilBosch K 12 V 5 Water temperature gauge sender 6 Reversing light switch 7 Oil pressure gauge sender 8 Microswitch for oil pressure warning light 9 Alternator . . . Bosch K 1 → 14 V 45 A 22 10 Starting motor Bosch EF (R) 12 V 0.7 PS 11 Horns 12 Battery 12 V - 60 Ah 13 Microswitches for brake fluid level warning light 14 Junction boxes & connectors 15 Voltage regulator . . .Bosch AD 1/14 V 16 Relay for horns 17 Front direction indicators bulb 21 W 18 Front parking lights bulb 5 W 19 Bulb for high/low beam headlamps 40/45 W 20 Side direction indicators bulb 4 W 21 Screen wiper (two speed) Bosch WS 4912 AR 2A (1) 22 Instrument light bulb 23 Fuel reserve warning light bulb 24 Blower warning light bulb 25 Alternator warning light bulb 26 Low oil pressure warning bulb 27 High beam warning light bulb 28 Choke warning light bulb 29 Parking light warning bulb 30 Direction indicator warning lights bulb 31 Stop light switch 32 Windscreen washer switch 33 Flasher unit 34 Glove box light switch 35 Glove box light bulb 5 W 36 Parking brake and brake fluid level warning light | <ul style="list-style-type: none"> 37 Parking brake and brake fluid level warning light bulb 1.2 W 38 Blower motor (2 speed) 39 Blower switch 40 Instrument panel light switch 41 Windscreen wiper switch 42 Ash tray light 3 W 43 Ash tray light switch 44 Cigarette lighter 45 Choke warning light switch 46 Parking brake warning light switch 47 Courtesy light in mirror 48 Ignition and starting switch 49 Horn control 50 Fusebox 51 Parking lights, headlamps and flashing switch 52 Direction indicator switch 53 Courtesy light microswitch on door jambs 54 Luggage boot light switch 55 Luggage boot light bulb 5 W 56 Fuel level sender 57 Rear direction indicators bulb 58 Parking & Stop light bulb 59 Reversing lights bulb 60 Number plate light bulb |
|--|---|
-
- | | | |
|---|---------|--|
| <ul style="list-style-type: none"> 23 Fuel reserve warning light bulb 24 Blower warning light bulb 25 Alternator warning light bulb 26 Low oil pressure warning bulb 27 High beam warning light bulb 28 Choke warning light bulb 29 Parking light warning bulb 30 Direction indicator warning lights bulb | } 3 W | |
| <ul style="list-style-type: none"> 26 Low oil pressure warning bulb 27 High beam warning light bulb 28 Choke warning light bulb 29 Parking light warning bulb 30 Direction indicator warning lights bulb | } 1.2 W | |
-
- | | |
|--|---|
| CABLE COLOR CODE | |
| <ul style="list-style-type: none"> A blue B white C orange G yellow H grey M brown N black R red S pink | <ul style="list-style-type: none"> V green Z violet AB blue/white AN blue/black BN white/black GN yellow/black HN grey/black RN red/black VN green/black |
-
- The figure following the color code on the diagram shows the wire gauge in mm².

PLATE ON FUSEBOX

- 1, 2, 3, 4 Main devices
- 5 Parking lights
- 6 Indicating devices
- 7 L.H. high beam
- 8 R.H. high beam
- 9 L.H. low beam
- 10 R.H. low beam

